

VLOCK V5

Wireless Door Bell



OVERVIEW

The Wireless Doorbell is a modern, eco-friendly solution that combines convenience, reliability, and smart design. Unlike traditional doorbells, this innovative device requires no batteries or complex wiring.

Instead, it harnesses the energy generated from a simple press of the button to power its wireless signal, ensuring hassle-free operation and long-term durability.

SPECIFICATION

Parameters	Transmitter	Receiver
Power Supply	Self-powered	AC100V-230V 50/60Hz
Power Consumption		0.25W
Chimes		38 chimes
Weight	31g	UK: 55.7g EN: 55.7g US/CN: 53g
Transmission Distance		Indoor Distance ≥ 50m In the open area ≥150m
RF Frequency		433 mhz
Product Size	66(L) x 40(W) x 20(H) mm	78(L) x 54(W) x 20(H) mm
Volume		≥ 50dB (at 1 meter)
Working Temperature	-20°C ~ +60°C	-10°C ~ +45°C

INSTRUCTIONS

1. Pairing: When the receiver is powered on, press and hold the pairing button and if the indicator light is constantly on, it is in pairing mode. Then press the transmitter button, the indicator light flashes once to indicate that the pairing is successful. The receiver can be paired with up to 5 transmitter. When the receiver has been paired with 5 transmitter, adding a new transmitter will automatically replace the first one.

2. Schematic Description:

- Within 1 minute after the receiver is powered on, press and the pairing button for 3 second.
- The indicator light is constantly on indicates that it is in pairing mode.
- Press the transmitter button, the indicator light flashes once to indicate the pairing is successful.

3. Clear the Pairing

- Within 1 minute after the receiver is powered on, press and hold the pairing button until the light flashes 3 times to clear the pairing. Then press any button again and the light will turn off, indicating the clearing is complete.

4. Chime Selection: When the receiver is powered on, press the chime selection button to change the chime among the built-in 38 chimes.

5. Volume Control: When the receiver is powered on, press volume button to change the volume between large, medium, and low volume.

